



Operation Guide for Vulcan Electric Convection Oven 045S

Following these simple instructions will ensure the successful operation of your rental appliance.

Aztec appliances are equipped with Nema #15-50p plugs, and will require you to have a 50 Amp, 250v Nema #15-50r receptacle. Please see photos below:



- A) Master switch
- B) Fan speed switch
- C) Thermostat
- D) Cool down switch



Operation of Oven

- 1) Ensure that master power switch (A) is in the OFF (right) position.
- 2) Plug unit into wall receptacle.
- 3) Turn master power switch to the ON (left) position.
- 4) Adjust thermostat (C) and fan speed switch (B) as needed.
- 5) Oven doors **MUST** be closed for the oven to operate.
- 6) When done cooking, oven cool switch (D) can be moved to the ON (up) position to operate fan with doors open.